

How to Effectively Install:

Cut the Tube square, remove all burrs and sharp edges.

Insert Tube through the Collet.

Push Tube through the O-ring until the Tube Stop is reached.

Pull the Tube back to secure with the Stainless Steel Gripper Teeth.

Disconnecting

Depressurize the line.

Press the Collet against the body and pull on the Tube.

